

## TR 1585 R Earth auger



### Документы

Engine assy

---

Crankcase and starter assy

---

Tank and air filter

---

Reduction gear


---

Handle assy and drills

---

Carburettor




---



## изображение Engine assy






Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	3	097000092AR	Screw				
2	1	097000059A	Spring				
3	1	098000010R	Manifold				
4	1	094500007R	Piston pin				
5	2	007201198R	Ring				
6	1	006000010	Bearing				
7	1	098000001R	Crankshaft				
8	1	098000312B	Piston assy Ø52				
9	2	3033074	Washer				
10	1	52010441A	Muffler				
11	1	005100906AR	Screw				
12	1	097000215A	Gasket set				
13	4	3833076R	Washer				
14	1	53030029R	Deflector				
15	1	094500028R	Key				
16	1	52010458AR	Gasket				
17	1	3055101R	Spark plug				
18	1	097000094CR	Gasket				
19	1	097000323A	Screw guide				
20	2	3801045R	Screw				
21	1	50010215R	Decompressor				
22	1	097000342A	Cover				
23	3	3801052R	Screw				
24	2	098000004R	Piston ring Ø52				
25	1	50102012F	Complete cylinder				
26	1	52010078AR	Starter lever				
27	1	006000102R	Cotter pin				
28	2	61052009BR	Screw				
29	1	53030037	Spring				
30	1	098000043	Fittings				
31	1	097000333R	Flange				
32	1	005100913B	Screw				
33	1	097000057R	Grommet				
34	1	097000280	Support				
35	1	53030049	Carburetor kit WJ-72A				
36	1	006000187	Grommet				BT6-055-03/08
37	1	53030054	Cable				BT6-055-03/08
38	1	53030019	Throttle cable				
39	1	004000059	Cotter pin				
40	1	3916003R	Washer				

I° serie / 1st series



fino al  
till  
bis  
hasta  
jusqu'a  
do



20-06-2007



60

dal  
from  
ab  
desde  
depuis  
od

21-06-2007




## изображение Crankcase and starter assy

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50140060	Handle				BT6-052-09/07
2	4	097000092AR	Screw				
3	1	50140056	Cap				BT6-052-09/07
4	1	098000079R	Starter rope				BT6-052-09/07
5	1	098000060AR	Spring				BT6-052-09/07
6	1	52010439CR	Pulley				BT6-052-09/07
7	5	3960017AR	Screw				BT6-052-09/07
8	1	3918006R	Washer				BT6-052-09/07
9	1	3908036R	Screw				BT6-052-09/07
10	5	3819005R	Washer				BT6-052-09/07
11	1	097000019C	Flange				BT6-052-09/07
12	1	52010495C	Starter kit				BT6-052-09/07
13	2	094000227	Screw				
14	2	006000315R	Washer				
15	2	3916004R	Washer				
16	1	53030054	Cable	SN 5648050063			BT6-053-01/08,
17	1	094600169AR	Spring				
18	1	094600097AR	Spark plug cap				
19	1	50200162R	Ignition coil	SN 5647240760			BT6-053-01/08
20	1	52012027	Pawl kit				
21	1	3916009R	Washer				
22	1	004000142R	Nut				
23	1	3833080R	Washer				
24	1	52010326BR	Flywheel	SN 5647240760			BT6-053-01/08
25	1	52010143A	Tank cap				
26	1	094500004R	Seal ring				
27	1	53030050B	Crankcase assy	SN 5647240760			BT6-053-01/08
28	1	099900006R	Bearing				
29	1	097000215A	Gasket set				
30	2	3023008R	Plug				
31	1	53030005	Bracket				
32	1	3960116	Screw				BT6-052-09/07
33	1	3801004	Screw				
34	1	53030022	Stud				
35	1	53030031	Plate				
36	1	53030001	Cover				
37	2	008200913R	Nut				
38	1	099900014R	Seal ring				
39	6	3833073R	Washer				
40	4	3801035	Screw				
41	1	006000064	Screw				
42	1	53030007	Bracket				
43	1	53030010R	Plate				
44	1	53030006	Bracket				

## изображение Crankcase and starter assy


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
45	1	3801016R	Screw				
46	4	3819006R	Washer				
47	4	3916005R	Washer				
48	6	3914003R	Nut				
49	2	3801032R	Screw				
50	1	4196163R	Screw				
51	1	3801015R	Screw				
52	1	006100303R	Screw				
53	1	50140055	Cover				BT6-052-09/07
54	1	52010410	Cap				BT6-052-09/07
55	1	52010404	Spacer				BT6-052-09/07
56	1	52010485BR	Starter pulley				BT6-052-09/07
57	1	52010489R	Cap				BT6-052-09/07
58	1	52010484BR	Flange				BT6-052-09/07
59	1	52012118BR	Complete spring				BT6-052-09/07
60	1	52010495C	Starter kit				BT6-052-09/07
61	1	53032018	Labels kit				
62	1	53030023	Cable		SN 5647240759		BT6-053-01/08
63	1	53030038AR	Ignition coil		SN 5647240759		BT6-053-01/08
64	1	52010136BR	Flywheel		SN 5647240759		BT6-053-01/08
65		53030050B	Crankcase assy	SN 5647240760			BT6-053-01/08



## изображение Tank and air filter

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	093000468AR	Screw				
2	1	098000136R	Cover				
3	1	098000092R	Air filter nylon				
4	1	53030060R	Clutch cover				
5	1	53030044R	Guard				
6	1	53030013	Support				
7	1	4098658AR	Breather valve				
8	1	4100308AR	Gasket				
9	4	3918005R	Washer				
10	4	3819006R	Washer				
11	4	3801011R	Screw				
12	1	3912011R	Nut				
13	1	50010218R	Fuel filter				
14	1	3059012	Band				
15	1	3049006R	O-ring				
16	1	3078010	Washer				
17	1	3055098R	Ring				
18	1	3055046R	Tap				
19	1	4098377R	Band				
20	1	53030018	Tube				
21	1	53030041R	Sheath				
22	1	4151258R	Complete cap				
23	1	53012004R	Fuel tank				
24	3	099900296R	Screw				
25	2	3914010R	Nut				
26	2	3818011AR	Washer				
27	2	3801048	Screw				
28	2	3914003R	Nut				
29	1	53030021	Support				
30	1	3088001R	Grommet				
31	1	094500183	Tube				











## изображение Reduction gear

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	028200063	Shaft				
2	1	028200010	Seal ring				
3	1	028200331	Cap				
4	1	028200038	Washer				
5	2	3024006R	Snap ring				
6	1	53010032	Pin				
7	1	53010028R	Cover				
8	1	53010084	Pin and rod kit				
9	1	53010031A	Lever				
10	1	53010034	Spring				
11	1	3033002	Ball				
12	1	3046020	Knob				
13	1	3914003R	Nut				
14	1	3918005R	Washer				
15	1	3801027R	Screw				
16	1	3833076R	Washer				
17	1	3918003R	Washer				
18	1	3072014	Washer				
19	1	3801003R	Screw				
20	1	3024009R	Ring				
21	1	028200065R	Washer				
22	1	028200066	Bearing				
23	1	028200067R	Sprocket				
24	1	028200009	Shaft				
25	1	028200013	Sprocket				
26	1	004000423	Washer				
27	1	028200011	Bearing				
28	1	028200021R	Bearing				
29	1	3806022R	Screw				
30	1	028200025	Plate				
31	1	028200022	Washer				
32	1	028200026	Chain sprocket				
33	1	028200027	Chain sprocket				
34	1	028200024	Spacer				
35	2	028200023R	Bearing				
36	1	028200034	Seal ring				
37	1	3024025	Ring				
38	1	028200119	Chain sprocket				
39	1	028200031R	Ring				
40	1	028200020	Bearing				
41	1	028200032	Spacer				
42	1	028200033R	Bearing				
43	1	028200014	Washer				
44	1	028200015	Bearing				

## изображение Reduction gear

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
45	1	028200016	Spacer				
46	1	028200017	Bearing				
47	1	028200018	Chain sprocket				
48	1	028200019	Ring				
49	1	3801010R	Screw				
50	1	028200007R	Gasket				
51	1	53010029	Gear case				
52	1	028200028	Shaft				
53	1	028200037	Cap				
54	1	028200036	Washer				
55	1	3819006R	Washer				
56	1	3801011R	Screw				
57	1	53010033	Slide				
58	1	028200039R	Screw				
59	1	028200040R	Washer				
60	1	53010066	Clutch drum				
61	1	012000041R	Bearing				
62	1	099900227R	Spring				
63	1	53030017AR	Clutch				
64	1	3049014R	O-ring				




## изображение Handle assy and drills

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	375100028A	Single flute bit Ø8x100 cm				
1	1	375100029A	Single flute bit Ø10x100 cm				
1	1	375100030A	Single flute bit Ø15x100 cm				
1	1	375100031A	Single flute bit Ø20x100 cm				
2	1	375100088AR	Cap 10÷50 cm				
2	1	375100090A	Cap 8 cm				
3	1	375100091AR	Blade 8 cm				
3	1	375100092AR	Blade cm 10				
4	1	375100093AR	Blade cm 15				
4	1	375100094AR	Blade cm 20				
5	1	3802007R	Screw				
6	1	320000028R	Nut				
7	1	53032012	Throttle lever				
8	1	53030061	Single flute bit Ø25x85 cm				BT6-076-11/10
8	1	53030062	Single flute bit Ø30x85 cm				BT6-076-11/10
8	1	53030063	Single flute bit Ø35x85 cm				BT6-076-11/10
9	2	028000055R	Screw				
10	2	028000067A	Blade cm 25				
10	2	028000068A	Blade cm 30				
10	2	028000069A	Blade cm 35				
10	2	028000078A	Blade cm 40				
10	2	028200255	Blade for bit Ø45				
10	2	028200256	Blade for Ø50 bit				
11	2	006000091R	Nut				
12	1	028200252	Double flute bit Ø45x100 cm				
12	1	028200253	Double flute bit Ø50x100 cm				
12	1	028200297	Double flute bit Ø25x100 cm				
12	1	028200298	Double flute bit Ø30x100 cm				
12	1	028200299	Double flute bit Ø35x100 cm				
12	1	028200306	Double flute bit Ø40x100 cm				
13	1	028200289	Extension				BT6-076-11/10
14	1	028200287	Extension				BT6-076-11/10
15	1	028200354	Support + pin kit				BT6-076-11/10
16	1	375100115	Extension + cotter pin				
17	1	YN5137500	Plug				BT6-076-11/10
18	1	3914006R	Nut				
19	1	53010007	Handle				

изображение Handle assy and drills

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
20	1	365100024	Throttle lever				
21	1	53030019	Throttle cable				
22	1	072700237	Band				
23	1	53010010	Screw				
24	1	3044103	Band				
25	1	53010009	Handle				
26	1	53030023	Cable				
27	2	3046021R	Knob				
28	1	53010055A	Support				
29	4	3806094R	Screw				
30	4	3819014R	Grower				
31	4	53010013	Pin				
32	2	3916008R	Washer				
33	2	3914010R	Nut				
34	1	3033141	Plug				BT6-076-11/10



■ 25 Kit riparazione / Repair kit

## изображение Carburettor

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	028400110	Shutter				
2	1	097000162	Screw				
3	1	097000162	Screw				
4	1	097000161	Spring				
5	1	097000154	Shaft				
6	1	097000155	Shaft				
7	1	2318763	Spring				
8	1	2318772	Screw L				
9	1	2318773	Screw H				
10	1	097000223	Spring				
11	2	097000224	Bushing				
12	5	035000162	Screw				
13	1	097000156	Cover				
14	1	097000323A	Screw guide				
15	1	035000169	Spindle				
16	1	035000164	Spring				
17	1	006000325	Ball				
18	1	50010141	Screw				
19	1	035000151	Shutter				
20	1	035000149	Plate				
21	1	097000160	Lever				
22	1	003300036	Fittings				
23	1	097000157	Cover				
24	4	035000161	Screw				
25	1	2318672	Repair kit				
26	1	2318695	Cap				
27	1	2318694	Cap				